



Connection Cable with Hasselblad H3D2 series back

Instructions



Code: 7092K



Connect the jack 2,5 (silver coloured) to the Sync In of the H3DII back and the e il jack 3,5 (gold coloured) to the Sync Out of the H3DII back.

Select Hasselblad H3DII mode from the menu in the Remote control unit (code D7020K).

In case the firmware of the DRCU has not been updated, select the Leaf Sync or Phase One 2 mode.

On the software for acquisition or on the back's menu, select the Camera interface: Pinhole.

