



# Actuator for Hasselblad V lenses

## Instructions



Please follow these instructions carefully when using the actuator:

1) Check that the shutter of the Hasselblad lens is loaded, otherwise load it with a flat screwdriver by mean of the special small wheel.



2) Load the Silvestri trigger system until the loading lever arrives to the end of its run.

3) It is only possible to attach the lens under these conditions, even if it fits in, it will not function.

4) Insert the lens on the loading system aligning the red dots.

5) Connect a **cable release suitable for Copal Press shutters!**

6) Make a single pressure on the cable release, the shutter will close when releasing this pressure.

7) Make a second pressure, the shutter will then perform the exposure time set on the lens.

